


SIGNALS FROM CONTROL


S1
S2

13 to 15
14 to 16

18 to 20
19 to 21



DO NOT DRILL THIS SIDE OF THE UNIT CONTROL. USE AVAILABLE KNOCK OUTS AT THE BOTTOM OF THE UNIT.



PN895-00439 Rev.00

| | |
|----------------|--------|
| WIRING DIAGRAM | |
| RB-2 | |
| S 891-00188 | Rev.03 |