


SIGNALS FROM CONTROL

S1  
S2  
S3


7 to 9  
8 to 10

13 to 15  
14 to 16

18 to 20  
19 to 21



DO NOT DRILL THIS SIDE OF THE UNIT CONTROL. USE AVAILABLE KNOCK OUTS AT THE BOTTOM OF THE UNIT.



PN895-00440 Rev.00

WIRING DIAGRAM	
<b>RB-3</b>	
S 891-00189	Rev.03