


This document displays the ISO-2S menus.  
Access to these menus depend on the particular configuration of the controller.



	Wall is opened (section A)
	Stage 1 is ON (section A)
	Stage 2 is ON (section A)
	Stage 3 is ON (section A)
	Stage 4 is ON (section A)
	Drying (section A)
	Chimney is not moving
	Chimney is closing
	Chimney is opening
	Chimney in manual mode
	Alarm



PN895-00637 REV 01


QUICK GUIDE <span style="float: right;">EN</span>	
ISO-2S MENU	
#892-00052	REV 01

Please scan the QR Code to access the complete manual or visit the website.  
AP: <http://www.automatedproduction.com>



GSI Electronics Inc. • 5200 Armand Frappier Saint-Hubert, Qc  
Canada J3Z 1G5 • Phone: 1-877-926-2777  
E-mail: [mtl\\_techsupport@agcocorp.com](mailto:mtl_techsupport@agcocorp.com)

Ce document montre les menus du ISO-2S.  
L'accès à ces menus dépend des réglages effectués dans l'appareil.



**Conditions Courantes**

- Mur ouvert (section A)
- Stage 1 actif (section A)
- Stage 2 actif (section A)
- Stage 3 actif (section A)
- Stage 4 actif (section A)
- Séchage (section A)
- Cheminée Arrêtée
- Cheminée Ferme
- Cheminée Ouvre
- Cheminée, Mode manuel
- Alarme

PN895-00637 REV 01

GUIDE RAPIDE (FR)

ISO-2S MENUS

#892-00052 REV 01

Veuillez scanner le code QR pour accéder aux manuels complets ou visiter le site Web.  
AP: <http://www.automatedproduction.com>



GSI Electronics Inc. • 5200 Armand Frappier Saint-Hubert, Qc  
Canada J3Z 1G5 • Phone: 1-877-926-2777  
E-mail: mtl\_techsupport@agcocorp.com